


DIESEL

A diagram showing a single terminal labeled "F1". The terminal is represented by a vertical line with a circular contact point at the top. To the right of the terminal, the label "F1" is printed above "FUSE/RELAY", which is above "BOX".

A1
INSTRUMENT
CLUSTER

x1 = 1 POLE
x2 = 4 POLE
x3 = 15 POLE
x4 = 3 POLE
x5 = 5 POLE



REVISIONS: